

HISTORY INFORMATION FOR THE FOLLOWING MANUAL:

SERVICE MANUAL

ORIGINAL MANUAL ISSUE DATE: 2017/6/27

GN3FK CHASSIS
Segment: KCL

Version	Date	Subject
1.0	2017/6/27	First version issue.
2.0	2017/8/16	Update page 10~15, 17~23
3.0	2017/10/23	Add STAND ASSY on page 10 and 17.
4.0	2018/1/12	Add new REMOTE COMMANDER P/N on page 16 and 24.
5.0	2018/4/20	U part Sony P/N removed.
6.0	2019/1/5	Add Light Bar replacing SOP on page 17~19, 28~30, 50~61, 71~86.

LCD Digital Color TV


SONY®

9-888-740-06

1-2. KD-60X690E/KD-60X695E/KD-60X697E/KD-60X6700E

DISASSEMBLY AND PARTS LIST

1-2-1. STAND BLOCK




1-2-2. STAND COVER ASSY AND STAND BASE ASSY AND NECK




1-2. KD-60X690E/KD-60X695E/KD-60X697E/KD-60X6700E

DISASSEMBLY AND PARTS LIST

1-2-3. AC COVER AND REAR COVER



REF.NO.	PART No.	DESCRIPTION	MARK
6	4-725-317-01	COVER, AC	
7	1-912-305-11	AC Cord(USA 2pin)	For UC2/LA1/CO1
	1-912-304-11	AC Cord(Argentina 2pin)	For AR4
	1-912-303-11	AC Cord(Europe 2pin)	For LA8/ME6
	1-912-301-11	AC Cord(UK 3pin)	For EA4
	1-912-302-11	AC Cord(AUS/NZ 2pin)	For AZ1
8	4-723-275-01	COVER, REAR (UC2)	ForUC2
	4-723-277-01	COVER, REAR (LA1/EA4/ME6)	ForLA1/EA4/ME6
	4-723-276-01	COVER, REAR (LA8/CO1/AR4)	ForLA8/CO1/AR4
	4-723-298-01	COVER, REAR (AZ1)	ForAZ1
9		BAG,PROTECTION PELD(L305xw127xt0.05mm)	
10	4-262-708-04	CLAMPER CABLE	
		SCREW, +PSW M3X8 W8	
		SCREW,ORNAMENTAL M6X12	
		SCREW, +BVTP 3X8 TYPE2 IT-3	



1-2. KD-60X690E/KD-60X695E/KD-60X697E/KD-60X6700E

DISASSEMBLY AND PARTS LIST

1-2-4. OVERALL

