


5. REPAIR PARTS LIST

5-1. EXPLODED VIEWS


5-1-1. OVERALL SECTION



5. REPAIR PARTS LIST

5-1-2. CABINET (REAR) SECTION


ns : not supplied



5. REPAIR PARTS LIST

5-1-3. MAIN SECTION

ns : not supplied




CAUTION :
 Danger of explosion if battery is incorrectly replaced.
 Replace only with the same or equivalent type.

5. REPAIR PARTS LIST

5-1-4. LENS SECTION

ns : not supplied




Be sure to read "Precautions upon replacing CCD imager" on page 4-3 when changing the CCD imager.

5. REPAIR PARTS LIST


5-1-5. CABINET (FRONT) SECTION

ns : not supplied




5. REPAIR PARTS LIST

5-1-6. ST SECTION




PRECAUTION DURING SOLENOID PLUNGER INSTALLATION




5. REPAIR PARTS LIST

Checking supplied accessories.

Make sure that the following accessories are supplied with your camcorder.




⚠Ni-MH battery charger BC-CS2A/CS2B (1)(




HR6 (size AA) Nickel-Metal
Hydride batteries (2)
(not supplied)



Adaptor ring (1)




Battery case (1)



Lens cap (1)



⚠Power cord (Mains lead) (1)




USB cable (1)




Lens cap strap (1)




AV cable (1)




CD-ROM
(Cyber-shot application software) (1)




Shoulder strap (1)



2-pin conversion adaptor (1)
(JE model)



Lens hood (1)



2-pin conversion adaptor (1)
(E model)