



ELECTROLUX HOME PRODUCTS PTY LTD
ABN 51 004 762 341

Technical Publication N° CE410.doc

Issue: 1
Date: 9/09

WEB SITE ADDRESS: www.partnship.com.au

WESTINGHOUSE

***ELECTRIC UNDERBENCH
EBONY***


MODEL:
EOEK62AK


First Built Dates:	
EOEK62AK	09/09

This exploded view diagram illustrates the assembly of a microwave oven. The main assembly shows the microwave body (11) with its internal components, including the magnetron (14), waveguide (15), and turntable (13). The door (4) is shown on the right, with its internal frame (7) and door panel (20). The control panel (22) is shown on the left, with its internal components (23, 24, 25, 26, 27) and mounting bracket (28). The diagram includes numerous numbered callouts (1-37) identifying specific parts and their assembly positions. Dashed lines indicate the alignment and movement of the components during assembly.

MODEL:


**EX. VIEW DRAWING 5615
PANEL DECK ASSEMBLY**






MODEL: EOEK62AK

**EX. VIEW DRAWING 7333
CONTROL PANEL ASSEMBLY**





MODEL: EOEK62AK

**EX. VIEW DRAWING 5814
INTERNAL PACK**

