


Before First Use

- Unpack your Steamer; remove and peel off any labels adhered to the unit.
- Remove and save instruction manual.
- Wipe outside of the unit with a damp cloth or sponge to remove any dust. Dry thoroughly.
- Keep unit on a flat, leveled surface.
- When using your Steamer for the first time, you may notice a small amount of smoke and a slight odor. This is normal when heating the appliance for the first time and there is no reason for concern.

Sunbeam Power Shot Handheld Garment Steamer



1. Heated press bar
2. Steam exit
3. Shot of steam button
4. Continuous steam switch
5. Removable water tank with water inlet tube
6. Red ready indicator light
7. Fabric Brush
8. Lint Brush