



# Electrolux

## SPARE PARTS LIST

Stick Rechargeable

0920

| Item | PNC       | ELC | Brand      | Model     | Market  |
|------|-----------|-----|------------|-----------|---------|
| A    | 900943272 | 00  | Electrolux | PQ91-3EB  | AUW/NZE |
| A    | 900943282 | 00  | Electrolux | PQ92-3PGF | AUW/NZE |

### **SAFETY WARNING**

**Always turn off and unplug the machine before detaching any parts.**


When servicing machines, do not remove  
ANY detachable parts while the machine is powered.  
The reason is internal faults may cause shorts to components  
that are normally at low voltage presenting a shock hazard.

|                          |  |                           |   |
|--------------------------|--|---------------------------|---|
| Electrolux SEA Pte. Ltd. |  | Publication-No.<br>200226 | Small Appliance<br>Vacuum Cleaner<br>Stick Rechargeable |
|--------------------------|--|---------------------------|---|

Model PNC

PQ91-3EB 900943272  
PQ92-3PGF 900943282

# Ex. View Drawing Housing, Motor and Filter




Model

PNC

PQ91-3EB  
PQ92-3PGF

900943272  
900943282

Ex. View Drawing  
Housing, Motor and  
Filter



ESKQ9



ZE137



99

EF167

