




SECTION 3: XR / XRM-85X95L

3-4. EXPLODED VIEW AND PART LIST

- Place the TV set facing downwards on a stable, level surface before disassembly and assembly of parts.
-  and shaded parts are critical for safety. Replace only with part number specified.
-  Parts contain confidential information. Strictly follow the instruction whenever the components are repaired and/or replaced

- ⚡ (*) Parts are not stocked since they are seldom required for routine service. Some delays should be anticipated when ordering these components.
- ⚡ Picture provided in this section might have slight difference from the actual sets.
- ⚡ The reference number beside the part indicates the disassembly sequence.
- ⚡ Remove screws before disassembly. Unplug connectors before disassembly



REF. NO		PART NO.	DESCRIPTION	REMARKS
	1	5-046-210-01	COVER TML V (3L PLD) A	Compatible
		5-046-210-11		
	2	5-046-212-01	STAND COVER LR (3L PLD) A	Including stand cover R & stand cover L
		5-046-212-11		
	3	5-046-214-01	STAND COVER CL (PLD) A	Compatible
		5-046-214-11		
	4	5-046-215-01	STAND COVER CR (PLD) A	Compatible
		5-046-215-11		

SECTION 3: XR / XRM-85X95L

3-4. EXPLODED VIEW AND PART LIST

- Place the TV set facing downwards on a stable, level surface before disassembly and assembly of parts.
 -  and shaded parts are critical for safety. Replace only with part number specified.
 -  Parts contain confidential information. Strictly follow the instruction whenever the components are repaired and/or replaced
- ✂ (*) Parts are not stocked since they are seldom required for routine service. Some delays should be anticipated when ordering these components.
 - ✂ Picture provided in this section might have slight difference from the actual sets.
 - ✂ The reference number beside the part indicates the disassembly sequence.
 - ✂ Remove screws before disassembly. Unplug connectors before disassembly

