



Single Wall Oven General Assembly Diagram




Oven Assembly; Main Oven




Qty Required
EW050
EW100
EW250

Switch Panel Assembly EW100



Door Assembly EW050,EW100,EW250 & EW300



Accessories

Description	EW050	EW100
	Oven Tray	3
Meat Dish Curved	1	
Grill Tray Curved	1	
Thumbscrew	3	
Screw	2	
Fibre Washer	2	
Side runner 2nd oven (RHS)	-	
Side runner 2nd oven (LHS)	-	
Oven Fan Baffle self-clean	1	
Grill Reflector 2nd Oven	-	
Oven Rack	3	
Grill Pan Curved	-	
Grill Pan Rack	-	
8 Rung side Runner (LHS)	1	
8 Rung Side Runner (RHS)	1	
Self Clean Panel	2	

