


■ Nozzle Assembly, Turbine



■ Nozzle Assembly, Mop (Spray Mop)




### ■ Handy Assembly



1	AJL302
2	AED702
3	AJJ702
4	EAC214




#### ■ Handy Assembly



#### ☐ Tank Assembly, Set

	Part name	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		


#### ■ Handy Assembly



### ■ Tank Assembly, Set (Compress Lever)

	Part Name	
1		
2		
3	é	
4		
5		
6		
7		
8		
9		


#### ■ Handle Assembly



	Part Name	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		




### ■ Cover Assembly Top



	Part Name
1	Cover Assembly, Top
2	Window, LCD
3	LCD, Module-TFT
4	Case, LCD
5	PCB Assembly
6	Cover, Décor
7	Decor, Hinge
8	Cover, Hinge
9	Cover, Exhaust Filter
10	Gasket, Sealing
11	Harness,Single



### ■ Cover FrontAssembly





		Part Name	
	1		
	2		
	3		
٢	4		
$\dashv$	5		
	6		
	7		
	8		
	9		
	10		

Should be replaced simultaneously




### ■ Supporter Cover Assembly





	Part Name	
1		AJJ702
2		
3		
4		
5		

### ■ Tank Assembly, Dust



	Part Name
1	
2	
3	
4	
5	
6	
7	
8	



#### **■** FrameAssembly







	Part Name	
1		
2		
3		
4		
5		
6		
7		
8	é	
9		
10		
11		
12		



### **■** Filter Assembly, Mesh





	Part Name	
1		
2		
3		
4		
5		
6		
7		
8		



### ■ Filter Assembly, Exhaust Filter





	Part Name	
1		
2		
3		
4		
5		
6		
7		



#### Accessories










#### ■ Battery



#### ■ Adjustable extension tube






#### ■ Power Drive Mini Nozzle





■ Dust emptying charging station\_3.0










■ Body Cover Assembly







■ Top Cover Assembly






■ Door Assembly








■ Duct Assembly\_3.0





#### ■ Chamber Assembly\_3.0

\* The Components of Product may vary depending on the model.





#### ■ Bottom Plate Assembly

