



Part Exploded View BX1 series

1.Part Expolded View : Body


No.6 Parts Breakdown



No.13 Parts Breakdown




2.Part Expolded View : Machine Room




3.Part Expolded View : Door


A.BX1-C/B series



B.BX1-G series




C.BX1-W series



※Parts No.63 , 64 : Only for BX471 series

A.BX1-G/C/B series



B.BX1-W series

