



Exploded view of structure and list of parts

■ Nozzle Assembly, Turbine



Exploded view of structure and list of parts


■ Nozzle Assembly, Mop (Spray Mop)





Exploded view of structure and list of parts

Handy Assembly




1		AJL302
2		AED702
3		AJJ702
4		EAC214



Exploded view of structure and list of parts

■ Handy Assembly




□ Tank Assembly, Set

	Part name	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		



Exploded view of structure and list of parts

Handy Assembly




Tank Assembly, Set (Compress Lever)

	Part Name	
1		
2		
3	é	
4		
5		
6		
7		
8		
9		



Exploded view of structure and list of parts

■ Handle Assembly




	Part Name	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		



Exploded view of structure and list of parts

■ Cover Assembly Top




	Part Name	
1	Cover Assembly, Top	
2	Window, LCD	
3	LCD, Module-TFT	
4	Case, LCD	
5	PCB Assembly	
6	Cover, Décor	
7	Decor, Hinge	
8	Cover, Hinge	
9	Cover, Exhaust Filter	
10	Gasket, Sealing	
11	Harness,Single	



Exploded view of structure and list of parts

■ Cover FrontAssembly





	Part Name	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

Should be replaced simultaneously



Exploded view of structure and list of parts

Supporter Cover Assembly




	Part Name	
1		AJJ702
2		
3		
4		
5		



Exploded view of structure and list of parts

Tank Assembly, Dust




	Part Name	
1		
2		
3		
4		
5		
6		
7		
8		



Exploded view of structure and list of parts

■ FrameAssembly




	Part Name	
1		
2		
3		
4		
5		
6		
7		
8	é	
9		
10		
11		
12		



Exploded view of structure and list of parts

■ Filter Assembly, Mesh




	Part Name	
1		
2		
3		
4		
5		
6		
7		
8		




Exploded view of structure and list of parts

Filter Assembly, Exhaust Filter



ADQ702



MDS602


	Part Name	
1		
2		
3		
4		
5		
6		
7		

Exploded view of structure and list of parts

■ Accessories



■ Battery



■ Adjustable extension tube






Exploded view of structure and list of parts

■ Nozzle Assembly, Turbine



Structural diagram


■ Cover Assembly



* Harness is included on the PCB.

Structural diagram

■ Base ASM



EBZ1101



EBZ4701




EBZ2401



* Harness is included on the PCB.

Structural diagram

■ Base ASM



EBZ2301




EBZ4301



EBZ4601




EBZ1601



* Harness is included on the PCB.



Structural diagram

■ Accessory




Exploded view of structure and list of parts

■ Station Assembly




Exploded view of structure and list of parts

■ Body Cover Assembly





Exploded view of structure and list of parts

■ Cover Assembly, Top




Exploded view of structure and list of parts

■ Door Assembly




Exploded view of structure and list of parts

■ Duct Assembly,Dust



Exploded view of structure and list of parts

■ Chamber Assembly / Cover Assembly



Exploded view of structure and list of parts

■ Base Assembly, Body

