



Electrolux

ELECTROLUX HOME PRODUCTS PTY LTD

ABN 51 004 762 341

Technical Publication N° CE745.docx


Issue: 2


Date: 3/16

ELECTROLUX

***ELECTRIC
PYRO DUO***

MODEL	PNC
EVEP623SB	944031670
EVEP626BB	944031671







MODELS: EVEP623SB

EVEP626BB

**EX. VIEW DRAWING 8174
CHASSIS ASSEMBLY**





This technical diagram illustrates the exploded view of a microwave oven assembly. The components are numbered as follows:

- 1**: Microwave oven door.
- 2**: Door hinge pin.
- 7**: Upper cabinet panel.
- 8**: Magnetron.
- 9**: Magnetron mounting bracket.
- 10**: Turntable motor.
- 11**: Turntable support ring.
- 12**: Turntable support plate.
- 13**: Waveguide cover.
- 14**: Waveguide.
- 15**: Turntable.
- 16**: Turntable guide rails.
- 17**: Microwave oven body.
- 18**: Upper cabinet panel.
- 21**: Door hinge bracket.
- 22**: Door hinge pin.
- 23**: Turntable guide pin.

