



## SECTION 2: EXPLODED VIEW AND PART LIST 65”

- Place the TV set facing downwards on a stable, level surface before disassembly and assembly of parts.
-  and shaded parts are critical for safety. Replace only with part number specified.
-  Parts contain confidential information. Strictly follow the instruction whenever the components are repaired and/or replaced

- ✂ (\*) Parts are not stocked since they are seldom required for routine service. Some delays should be anticipated when ordering these components.
- ✂ Picture provided in this section might have slight difference from the actual sets.
- ✂ The reference number beside the part indicates the disassembly sequence.
- ✂ Remove screws before disassembly. Unplug connectors before disassembly

