


## 22. Exploded View and Replacement Parts List

### 22.1 Indoor Unit

#### 22.1.1 CS-RZ25XKRW CS-RZ35XKRW CS-RZ42XKRW CS-RZ50XKRW



#### Note

The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.