




PARTS

OUTDOOR UNIT
AOTG18LVCC
AOTG22LVCC









OUTDOOR UNIT
AOTG18LVCC





ACCESSORIES

INDOOR UNIT

Name and Shape	Q'ty
Bracket panel 	1
Remote control 	1
Battery 	2
Remote control holder 	1
Cloth tape 	1
Tapping screw (big) 	8
Tapping screw (small) 	2
Anti virus filter 	2
Seal A 	1



Refer to each installation manual for the method of installing optional parts.

Parts name	Model No.	Use
Wired remote control *	UTY-RNNYN	For air conditioner operation
Simple remote control *	UTY-RSNYN	For air conditioner operation
External connect kit *	UTY-XWZXZ5	For control input/output port
Communication kit	UTY-TWBXF	For the installation of optional parts

* Optional communication kit is necessary for the installation.

"Demand response" for outdoor unit

Parts list for demand control option PCB kit (optional parts)

Parts name	Q'ty	Use
Demand control option PCB, Option PCB holder 	1	
Connector cable 	1	For connecting the demand control option PCB
Cable ties with clips 	1	For fixing the signal transmission cable
Cable ties 	2	For fixing the EMI core and the signal transmission cable (one is a spare)
Tapping screw 	1	For attaching the option PCB holder
EMI core 	1	Attached to the signal transmission cable