

SPLIT TYPE
ROOM AIR CONDITIONER
WALL MOUNTED TYPE


SERVICE MANUAL

Indoor unit	Outdoor unit
ASTG14LUCB	AOTG14LUCB




PARTS

OUTDOOR UNIT




Ref.	Description
1	Front Panel Assy
2	Emblem
3	Cabinet Left
4	Top Panel Assy
5	Protective Net
6	Switch Cover A Assy
7	Switch Cover B
8	Grip
9	Cabinet Right Assy
10	Valve Bracket
11	Separator Assy
12	Reactor Assy
13	Motor Bracket Assy
14	Fan Motor
15	Propeller Fan
16	Base Assy
--	Drain Assy

OUTDOOR UNIT



Ref.	Description
21	Condenser Total Assy
22	Compressor Assy
23	2 way Valve Assy
24	3 way Valve Sub Assy
25	4 way Valve Assy
26	Solenoid
27	Pulse Motor Valve Assy
28	Expansion Valve Coil

OUTDOOR UNIT



Ref.	Description
31	Sealed Panel
32	Main PCB
33	PCB Holder
34	Inverter Case Assy
35	Terminal Bracket
36	Terminal
--	Outdoor Thermistor
--	Thermistor Assy