

SPLIT TYPE
ROOM AIR CONDITIONER
CEILING WALL TYPE
INVERTER


SERVICE MANUAL




Indoor unit
AWTZ14LBC
AWTZ14LBC
AWTZ18LBC
AWTZ18LBC

DISASSEMBLY ILLUSTRATION


INDOOR UNIT



INDOOR UNIT
Casing assy



INDOOR UNIT






PARTS LIST

INDOOR UNIT

Ref. No.	Description
1	Air Filter
2	Dust Box Assy
3	Front Panel Assy
4	Open Panel Assy
5	Top Grill
6	Top Cover
7	Under Cover
9	Casing Assy
10	Louver U Assy
11	Louver U
12	Louver Frame
13	Spring EL
14	Louver Z
15	Spring F
16	Diffuser U
17	Diffuser Z
18	Spring C
19	Casing Cover F
20	Casing Cover B
21	Casing Cover L
22	Casing Cover R
23	Bushing-A
24	Louver Cam
25	Tension A
26	Spring Holder
27	Gear A
28	Drain Hose Assy
29	Drain Cap Assy
30	Evaporator Assy
31	Evaporator Assy B
32	Evaporator Assy C
33	Joint Pipe Assy
36	Senser Case
37	Sensor Cover
40	Motor Cover
41	Crossflow Fan Assy
42	Bearing C Assy
43	Control Box
44	Control Cover
46	Receiver Case
47	Cord Clamp
48	Evaporator Holder R
49	Evaporator Holder L
50	Rear Bracket
51	Controller PCB Assy
52	Power Cord Assy
53	Display Assy
54	Fan Motor Assy
56	Stepping Motor U
57	Stepping Motor Z
58	Connector w/Wire S
60	UV Unit Assy
61	Remote Controller Assy
62	Gear Box Assy
---	Room Temp. Thermistor
---	Pipe Temp. Thermistor
---	Fuse 3A
---	Relay

ACCESSORIES

The following installation accessories are supplied.
Use them as required.

Name and Shape	Q'ty	Name and Shape	Q'ty
Wall hook bracket  9312011018	1	Drain pipe  9303029022	1
Remote control  9314157028	1	Cloth tape  9308117007	1
Battery  0600185046	2	Tapping screw (big)  0700076046	8
Remote control unit holder  9312947010	1	Tapping screw (small)  0700019036	2
		Seal A  9304536000	1

0601G2992