PARTS MANUAL

Freestanding Range

OR61S2CEWW3 EL AA


Product Code
85262-C

AA

ELBA


BY FISHER & PAYKEL

SPLASHBACK COMPONENTS




DWG 003831

RADIANT HOB COMPONENTS




DWG 003832

CHASSIS COMPONENTS




DWG 003833

OVEN LINER COMPONENTS




DWG 003834

WARMER DRAWER COMPONENTS




DWG 003835

DOOR COMPONENTS



DWG 004535

ACCESSORIES



DWG 003837

www.fisherpaykel.com

Copyright © Fisher & Paykel Appliances Ltd 2017. All rights reserved.
The product specifications in this manual apply to the specific model described at the date of issue. Under our policy of continuous product improvement, these specifications may change at any time. Only use this manual if the product code on the front matches the product code on the serial label of the product.

AA

PRODUCT CODE: 85262-C 08.17