

NOTE:

Example:

KNOB, BALANCE (WHITE) . . . (RED)

Parts Color	Cabinet's Color
-------------	-----------------

- Abbreviation

AR : Argentina model

AUS : Australian model

CH : Chinese model

CND : Canadian model

E32 : Latin America n

- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The mechanical parts with no reference number in the exploded views are not supplied.

EA : Saudi Arabia model

RU : Russian model

SP : Singapore model

TH : Thai model

TW : Taiwan model


The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.


原理图和零件清单中标有△记号的零部件、或带有△记号的虚线所圈示的零部件，对于维系安全至关重要。因此只能以指定号码的零部件来更换。

5-1. SPEAKER CABINET ASSY (SA-WSIS10)



Note: When installing Ref. No. 3 in the cabinet, please refer to SECTION 3 DISASSEMBLY “3-7. Loudspeaker (12 cm) (Middle) (SP002)” (page 9).


5-2. AMP SECTION (SA-WSIS10)

**CAUTION**

When touching a AMP board, there is a shocked thing.
Please be sure to refer to SERVICING NOTES "DSP/AMP/
POWER Boards Service Position (SA-WSIS10)" (page 4) and
do discharge processing.

Note: If wire (flat type) is replaced, install it after
bending it in the same form as that before
replacement.

5-3. POWER BOARD SECTION (SA-WSIS10)

**CAUTION**

When touching a terminal for a condenser (C903) in POWER board, there is a shocked thing.
Please be sure to refer to SERVICING NOTES "DSP/AMP/ POWER Boards Service Position (SA-WSIS10)" (page 4) and do discharge processing.

5-4. SS-IS10

